

Page i

# TERMS, DEFINITIONS, ABBREVIATIONS, SYMBOLS AND UNITS FOR DISCRETE NON-MICROWAVE SEMICONDUCTOR DEVICES ESCC Basic Specification No. 2135000

## ISSUE 1 October 2002





#### **ESCC Basic Specification**

PAGE ii

ISSUE 1

#### **LEGAL DISCLAIMER AND COPYRIGHT**

European Space Agency, Copyright © 2002. All rights reserved.

The European Space Agency disclaims any liability or responsibility, to any person or entity, with respect to any loss or damage caused, or allleged to be caused, directly or indirectly by the use and application of this ESCC publication.

This publication, without the prior permission of the European Space Ageny and provided that it is not used for a commercial purpose, may be:

- copied in whole in any medium without alteration or modification.
- copied in part, in any medium, provided that the ESCC document identification, comprising the ESCC symbol, document number and document issue, is removed.



## european space agency agence spatiale européenne

Pages 1 to 17

## TERMS, DEFINITIONS, ABBREVIATIONS, SYMBOLS AND UNITS FOR DISCRETE NON-MICROWAVE SEMICONDUCTOR DEVICES

ESA/SCC Basic Specification No. 2135000



## space components coordination group

	Date	Approved by	
Issue/Rev.		SCCG Chairman	ESA Director General or his Deputy
Issue 1	September 1994	Tommens	Hours



PAGE 2

ISSUE 1

#### **DOCUMENTATION CHANGE NOTICE**

DOCUMENTATION CHANGE NOTICE				
Rev. Letter	Rev. Date	Reference	CHANGE Item	Approved DCR No.
:				



PAGE 3

#### **TABLE OF CONTENTS**

1.	<u>SCOPE</u>	<u>Page</u> <b>4</b>
2.	TERMS, DEFINITIONS AND ABBREVIATIONS	4
2.1	Diodes	4
2.1.1	Low Power Switching Diodes	4
2.1.2	Tunnel Diodes	5
2.1.3	Rectifier Diodes	6
2.1.4	Voltage Reference	7
2.2	Thyristors	7
2.3	Transistors	9
3.	GRAPHIC SYMBOLS	16
3.1	Diodes	16
3.2	Thyristors	16
3.3	Transistors	17
3.4	Field-effect Transistors	17



PAGE

ISSUE 1

4

#### 1. **SCOPE**

This specification forms part of ESA/SCC Basic Specification No. 21300, Terms, Definitions, Abbreviations, Symbols and Units, and covers discrete non-microwave semiconductor devices.

#### 2. **TERMS, DEFINITIONS AND ABBREVIATIONS**

#### 2.1 DIODES

#### 2.1.1 Low Power Switching Diodes

#### **Voltages**

Forward Continuous (Direct) Voltage (V<sub>F</sub>) - Forward voltage is the voltage drop which results from the flow of forward current through the semiconductor diode.

Instantaneous Total Forward Voltage (V<sub>F</sub>)

Average Forward Voltage (V<sub>F(AV)</sub>)

Reverse Continuous (Direct) Voltage (VR) - Reverse voltage is the voltage drop which results from the flow of reverse current through the semiconductor diode.

Instantaneous Total Reverse Voltage (V<sub>R</sub>)

Peak Reverse Voltage (V<sub>RM</sub>)

Surge Reverse Voltage (V<sub>RSM</sub>)

Breakdown Voltage (V(BR))

- The breakdown voltage is the voltage measured at a specified current in the breakdown region.

#### Currents

Forward Continuous (Direct) Current (I<sub>F</sub>)

Forward current is the current flowing through the diode in the direction of lower resistance to the flow of steady direct current.

Instantaneous Forward Current (i<sub>F</sub>)

Peak Forward Current (F<sub>M</sub>)

Surge Forward Current (IFSM)

- The surge current is the maximum current pulse which can be carried by the semiconductor or diode for the length of time, repetition frequency and waveform specified.

Average Output Rectified Current (I<sub>O</sub>)

Reverse Continuous (Direct) Current (I<sub>R</sub>)

- The reverse current is the current flowing through the diode in the direction of higher resistance to steady direct current when a specified reverse voltage is applied.



PAGE 5

ISSUE 1

Instantaneous Reverse Current (i<sub>R</sub>)

Peak Reverse Current (I<sub>RM</sub>)

#### **Powers**

Surge Non-repetitive Power (IPSM)

#### **Switching Parameters**

Forward Recovery Time (t<sub>fr</sub>)

- The forward recovery time is the time required for the current or voltage to reach a specified condition after instantaneous switching from 0 or a specified reverse voltage to a specified forward biased condition.

Reverse Recovery Time (t<sub>rr</sub>)

 The reverse recovery time is the time required for the current or voltage to reach a specified condition after instantaneous switching from a specified forward current to a specified reverse biased condition.

Reverse Recovery Current (irr)

Recovered Charge (Stored Charge) (Qs)

#### **Sundry Quantities**

Differential Resistance (r)

Damping Coefficient (δ or d)

Damping Resistance (r<sub>δ</sub> or r<sub>d</sub>)

Efficiency (η)

Rectification Efficiency (n<sub>r</sub>)

#### 2.1.2 <u>Tunnel Diodes</u>

#### **Voltages and Currents**

Peak Point Current (I<sub>0</sub>)

Valley Point Current (I<sub>v</sub>)

 Valley current is the current measured at the positive voltage at which the current has reached a minimum value from which it will increase if the voltage is increased further.

Peak-to-Valley Point Current Ratio (Ip/Iv)

Reverse Continuous (Direct) Current (I<sub>R</sub>)

Peak Point Voltage (V<sub>P</sub>)

- Peak point voltage is the voltage at which peak point current occurs.

Valley Point Voltage (V<sub>v</sub>)

Valley voltage is the voltage at which valley current occurs.



PAGE 6 ISSUE 1

Projected Peak Point Voltage (Vpp)

Reverse Continuous (Direct) Voltage (V<sub>R</sub>)

#### 2.1.3 **Rectifier Diodes**

#### Voltages

Continuous (Direct) Forward Voltage (V<sub>f</sub>)

Forward voltage is the voltage drop which results from the flow of forward current through the semiconductor diode.

Crest (Peak) Forward Voltage (V<sub>FM</sub>)

Average Forward Voltage (V<sub>F(AV)</sub>)

- With IO specified.

Continuous (Direct) Reverse Voltage (V<sub>R</sub>)

Crest (Peak) Working Reverse Voltage (V<sub>RWM</sub>)

Repetitive Peak Reverse Voltage (V<sub>RRM</sub>) - Maximum recurrent reverse voltage.

Non-repetitive Peak Reverse Voltage

 $(V_{RSM})$ 

- Peak transient reverse voltage.

Breakdown Voltage (V(BR))

Threshold Voltage (V<sub>TO)</sub>)

#### Currents

Continuous (Direct) Forward Current (I<sub>F</sub>)

Repetitive Peak Forward Current (IFRM)

Overload Forward Current (I<sub>(OV)</sub>)

Surge (Non-repetitive) Forward Current (I<sub>FSM</sub>)

- The surge current is the maximum current pulse which can be carried by the semiconductor diode for the length of time, repetition frequency and waveform specified.

Average Output Rectified Current (Io)

Continuous (Direct) Reverse Current (I<sub>R</sub>)

Average Reverse Current (IR(AV))

- With Io specified.

#### **Sundry Quantities**

Slope Resistance (r<sub>T</sub>)



PAGE 7 ISSUE 1

#### 2.1.4 Voltage Reference

Voltage Regulator Diode Current (I<sub>K</sub>) near Breakdown Knee

Voltage Regulator Diode Current (I<sub>Z</sub>)

Voltage Regulator Impedance (Z<sub>K</sub>) near Breakdown Knee (I<sub>K</sub>)

#### 2.2 **THYRISTORS**

#### **Principal Voltages - Anode-Cathode Voltages**

Continuous (Direct) Off-state Voltage (VD) - The off-state is the condition of the device corresponding to the portion of the anode-cathode voltage current characteristic for forward currents less than the forward break-over current.

Peak Off-state Voltage (V<sub>DM</sub>)

Crest (Peak) Working Off-state Voltage (V<sub>DWM</sub>)

Repetitive Peak Off-state Voltage (VDRM)

Non-repetitive Peak Off-state Voltage (V<sub>DSM</sub>)

Break-over Continuous (Direct) Voltage (V<sub>(BO)</sub>)

- The forward break-over voltage is the maximum positive voltage from anode to cathode for which the small signal is 0 for a specified gate current.

Continuous (Direct) On-state Voltage (V<sub>T</sub>)

Minimum On-state Voltage (V<sub>TMIN</sub>)

On-state Threshold Voltage (V<sub>T(TO)</sub>)

Continuous (Direct) Reverse Voltage (V<sub>R</sub>)

Crest (Peak) Working Reverse Voltage (V<sub>RWM</sub>)

- The working peak reverse voltage is the maximum instantaneous value of the reverse voltage, excluding all repetitive and non-repetitive transient voltages which occur across the device.

Repetitive Peak Reverse Voltage (V<sub>RRM</sub>)

The repetitive peak reverse voltage is the maximum instantaneous value of the reverse voltage, including all repetitive transient voltages, but excluding all non-repetitive transient voltages which occur across the device.



PAGE 8

ISSUE 1

Non-repetitive Peak Reverse Voltage (V<sub>RSM</sub>)

 The non-repetitive peak reverse voltage is the maximum instantaneous value of the reverse voltage, including all non-repetitive transient voltages, but excluding all repetitive transient voltages which occur across the device.

Reverse Breakdown Voltage (V<sub>(BR)</sub>)

 The reverse breakdown voltage is the value of negative value from anode to cathode at which a transition commences from a region of high small signal resistance to a region of substantially lower small signal resistance between the anode and the cathode

#### **Principal Currents - Anode-Cathode Currents**

Continuous (Direct) Off-state Current (ID)

Continuous (Direct) Break-over Current (I<sub>(BO)</sub>)

- The forward break-over current is the current through the device at forward break-over voltage.

Continuous (Direct) Holding Current (I<sub>H</sub>)

- The holding current is the minimum current through the anode required to maintain the device in the on-state for specified gate conditions and load.

Continuous (Direct) On-state Current (I<sub>T</sub>)

 The on-state is the condition of the device corresponding to the low impedance low voltage portion of the anode to cathode voltage current characteristic for positive anode to cathode voltage.

Overload On-state Current (I(OV))

Repetitive Peak On-state Current (ITRM)

Surge (Non-repetitive) On-state Current (I<sub>TSM</sub>)

Continuous (Direct) Reverse Blocking Current (I<sub>R</sub>)

Repetitive Peak Reverse Current (IRRM)

#### **Gate Voltages**

(The gate voltage is the voltage between the gate and the terminal of the adjacent region).

Forward Gate Continuous (Direct) Voltage (V<sub>FG</sub>)

Peak Forward Gate Voltage (V<sub>FGM</sub>)

Reverse Gate Continuous (Direct) Voltage (V<sub>RG</sub>)

Peak Reverse Gate Voltage (V<sub>RGM</sub>)



PAGE

ISSUE 1

9

Gate Trigger Continuous (Direct) Voltage (V<sub>GT</sub>)

- The gate trigger voltage is the voltage between the gate and the terminal of the adjacent region required to produce the gate trigger current.

Minimum Gate Trigger Voltage (VGTMIN)

Gate Non-trigger Continuous (Direct) Voltage (V<sub>GD</sub>)

Gate Turn-off Continuous (Direct) Voltage (V<sub>GQ</sub>)

- The gate turn-off voltage is the voltage between the gate and the terminal of the adjacent region required to produce the gate turn-off current.

#### **Gate Currents**

(The gate current is the current through the gate).

Forward Gate Continuous (Direct) Current (I<sub>FG</sub>)

Peak Forward Gate Current (IFGM)

Reverse Gate Continuous (Direct) Current (I<sub>RG</sub>)

Gate Trigger Continuous (Direct)
Current (I<sub>GT</sub>)

 The gate trigger current is the minimum gate current required to cause switching from the off-state to the on-state for a stated anode to cathode voltage.

Gate Non-trigger Continuous (Direct) Current (I<sub>GD</sub>)

Gate Turn-off Continuous (Direct) Current (I<sub>GQ</sub>)  The gate turn-off current is the minimum gate current required to cause switching from the on-state to the off-state for a stated anode current in the on-state.

#### **Time Quantities**

Gate-controlled Turn-on Time (t<sub>qt</sub>)

Gate-controlled Turn-off Time (tgq)

Circuit-commutated Recovery Time (t<sub>0</sub>)

- Circuit-commutated turn-off time.

#### **Sundry Quantities**

On-state Slope Resistance (r<sub>T</sub>)

#### 2.3 TRANSISTORS

#### Voltages

Collector-Base (d.c.) Voltage (V<sub>CB</sub>)

Collector-Emitter (d.c.) Voltage (VCE)

Emitter-Base (d.c.) Voltage (VEB)



PAGE 10

ISSUE 1

Base-Emitter (d.c.) Voltage (VBE)

Collector-Base (d.c.) Voltage (V<sub>CBO</sub>)

- With  $I_E = 0$ ;  $I_C$  specified.

Emitter-Base (d.c.) Voltage (V<sub>EBO</sub>)

- With I<sub>C</sub> = 0; E<sub>E</sub> specified.

Collector-Emitter (d.c.) Voltage (V<sub>CEO</sub>)

- With I<sub>B</sub> = 0; I<sub>C</sub> specified.

Collector-Emitter (d.c.) Voltage (V<sub>CER</sub>)

- With R<sub>BE</sub> = R; I<sub>C</sub> specified.

Collector-Emitter (d.c.) Voltage (V<sub>CES</sub>)

- With V<sub>BE</sub> = 0; I<sub>C</sub> specified.

Collector-Emitter (d.c.) Voltage (V<sub>CEX</sub>)

With V<sub>BE</sub> = X specified (reverse biased Emitter-Base);
 I<sub>C</sub> specified.

Breakdown Voltage Open Circuit (V<sub>(BR)..0</sub>)

- The abbreviation BV is in common use for these quantities.

Breakdown Voltage, Collector-Base  $(V_{BR)CBO})$ 

- With I<sub>E</sub> = 0; I<sub>C</sub> specified.

Breakdown Voltage, Emitter-Base (V<sub>(BR)EBO)</sub>

With I<sub>C</sub> = 0; I<sub>C</sub> specified.
 Breakdown voltage is the voltage measured at a specified current in the breakdown region.

Breakdown Voltage, Collector-Emitter (V<sub>(BR)CEO)</sub>

- With I<sub>B</sub> = 0; I<sub>C</sub> specified.

#### **Breakdown Voltages**

(Specified circuit)

- The abbreviation BV is in common use for these quantities.

Breakdown Voltage, Collector-Emitter (V<sub>(BR)CER)</sub>

- With RBE = R; IC specified.

Breakdown Voltage, Collector-Emitter (V<sub>(BR)CEX</sub>)

\_\_\_\_\_

Breakdown Voltage Short Circuit (V<sub>(BR)...S</sub>) - The abbreviation BV is in common use for this quantity.

Breakdown Voltage, Collector-Emitter (V<sub>(BR)CES</sub>)

- With V<sub>BE</sub> = 0; I<sub>C</sub> specified.

Floating Voltage, Emitter-Base (V<sub>EBfi</sub>)

- With I<sub>E</sub> = 0; V<sub>CB</sub> specified.

A floating potential is the d.c. voltage between an open-circuited terminal and the reference point when a d.c. voltage is applied to the other terminals as specified.

Punch-through (Penetration) Voltage (Vot)

Saturation Voltage, Collector-Emitter (V<sub>CEsat</sub>)

- With I<sub>B</sub> = specified; I<sub>C</sub> specified.

The saturation voltage is the d.c. voltage between the measurement electrode and the reference electrode for specified saturation conditions.



PAGE 11

ISSUE 1

Saturation Voltage, Base-Emitter (V<sub>BEsat</sub>) - With I<sub>B</sub> specified, I<sub>C</sub> specified.

Currents

Base (d.c.) Current (l<sub>B</sub>)

Collector (d.c.) Current (I<sub>C</sub>)

Emitter (d.c.) current (I<sub>E</sub>)

Collector Cut-off Current (I<sub>CBO</sub>)

Collector Cut-off Current (I<sub>CEO</sub>)

Emitter Cut-off Current (I<sub>EBO</sub>)

Collector Cut-off Current (I<sub>CER</sub>)

Collector Cut-off Current (I<sub>CES</sub>)

Collector Cut-off Current (I<sub>CEX</sub>)

Base Cut-off Current (IBEX)

With I<sub>E</sub> = 0; V<sub>CB</sub> specified.

- With I<sub>B</sub> = 0; V<sub>CE</sub> specified.

- With I<sub>C</sub> = 0; V<sub>EB</sub> specified.

- With RBE = R; VCE specified.

- With V<sub>BE</sub> = 0; V<sub>CE</sub> specified.

- With V<sub>BE</sub> = X; V<sub>CE</sub> specified.

- With V<sub>BE</sub> = X; V<sub>CE</sub> specified.

**Powers** 

Collector Power Dissipation (P<sub>C</sub>)

Total Input Power (d.c. or average)

to all Electrodes (Ptot)

With T<sub>amb</sub> or T<sub>case</sub> specified.

- With Tamb or Tcase specified.

#### **Electrical Parameters**

STATIC PARAMETERS (Specified for bias conditions)

Static Value of the Forward Current Transfer Ratio:

- In Common Emitter Configuration (h<sub>21E</sub> or h<sub>FE</sub>)
- Static forward current transfer ratio is the ratio of the d.c. output current to the d.c. input current under specified test conditions.
- $h_{21E} = \frac{IC}{IB} = \frac{IE 1}{IB}$  with  $V_{CE} = constant$ .

SMALL SIGNAL PARAMETERS (Specified for bias and frequency conditions)

Small signal value of the Open-Circuit

- Reverse Voltage Transfer Ratio:
- In Common Emitter configuration (h12e or h<sub>re</sub>)
- In Common Base configuration (h12b or h<sub>rb</sub>)
- Small signal open-circuit reverse voltage transfer ratio is the ratio of the a.c. input voltage to the a.c. output voltage, with 0 a.c. input current.
- h12e =  $\frac{\text{Vbe}}{\text{Vce}}$  with  $I_b$  = constant.
- $h12b = \frac{Veb}{Vch}$  with  $l_e = constant$ .



PAGE 12

ISSUE 1

Small signal value of the Short-Circuit Forward Current Transfer Ratio:

- In Common Emitter configuration (h21e or h<sub>fe</sub>)
- In Common Base configuration (h21b or h<sub>fb</sub>)

Small signal value of the Open-Circuit Output Admittance:

- In Common Emitter configuration (h22e or h<sub>oe</sub>)
- In Common Base configuration (h22b or h<sub>ob</sub>)

#### **CAPACITANCE**

Input Capacitance:

- In Common Emitter configuration (C11es or Cies)
- In Common Base configuration (C11bs or Cibs)

**Output Capacitance:** 

 In Common Base configuration (C22bo or Cobo)

Output Capacitance:

- In Common Emitter configuration (C22es or Coes)
- In Common Base configuration (C22bs or Cobs)

FREQUENCY PARAMETERS

Cut-off Frequency:

 In Common Emitter configuration (fh21e or fhfe) - Small signal short-circuit forward current transfer ratio is the ratio of the a.c. output current to the a.c. input current, with 0 a.c. output voltage.

- 
$$h21e = \frac{IC}{Ib}$$
 with  $V_{ce} = constant$ .

- 
$$h21b = \frac{lc}{le}$$
 with  $V_{cb} = constant$ .

- Small signal open-circuit output admittance is the ratio of the a.c. output current to the a.c. voltage applied to the output terminals, with 0 a.c. input current.
- $h22e = \frac{Ic}{Vce}$  with  $I_b = constant$ .
- $h22b = \frac{lc}{Vcb}$  with  $l_e = constant$ .

- Output short circuited to a.c.

- h11b = Re (h11b) + 
$$\frac{1}{i\omega C11bs}$$

- Input open-circuited to a.c.
- $h22b = Re (h22b) + i\omega C22bo$
- Input short-circuited to a.c.
- y22e = Re (y22e) + iωC22es
- y22b = Re (y22b) +  $i\omega$ C22bs



PAGE 13

ISSUE 1

- In Common Base configuration (fh21b or fhfb)
- In Common Collector configuration (fh21c or fhfc)

Frequency of Unity Current Transfer Ratio (f<sub>i</sub>)

-  $fT = f \times h21e = 1$ 

Transistor Frequency (f<sub>T</sub>)

- fT+f×h21e (h21e is measured in a region when

(h21e is measured in a region where the roll-off is 6.0dB/octave).

Maximum Frequency of Oscillation (fmax)

 The maximum frequency of oscillation is the highest frequency at which a transistor will oscillate under specified conditions.

#### N.B.

This also approximates the frequency at which maximum available power gain has decreased to unity.

#### SWITCHING PARAMETERS

Pulse Average Time

Symbol under consideration.

The average pulse time of a pulse is the time duration from a point on the leading edge which is 50% of the maximum amplitude to a point on the trailing edge which is 50% of the maximum amplitude.

Pulse Time (t<sub>p</sub>)

- The pulse time of a pulse is the time interval from the point on the leading edge which is 90% of the maximum amplitude to a point on the trailing edge which is 90% of the maximum amplitude.

**Duty Cycle** 

- Symbol under consideration.

Delay Time (t<sub>d</sub>)

 The delay time of a pulse is the time interval from a point at which the leading edge of the input pulse has risen to 10% of its maximum amplitude to a point at which the leading edge of the output pulse has risen to 10% of its maximum amplitude.

Rise Time (t<sub>r</sub>)

The rise time of a pulse is that time duration during which the amplitude of its leading edge is increasing from 10% to 90% of the maximum amplitude.

Carrier Storage Time (ts)

- The storage time of a pulse is the time interval from a point 10% down from the maximum amplitude on the trailing edge of the input pulse to a point 10% down from the maximum amplitude on the trailing edge of the output pulse.



PAGE 14

ISSUE 1

Fall Time (t<sub>f</sub>)

The fall time of a pulse is that time duration during which the amplitude of its leading edge is decreasing from 90% to 10% of the maximum amplitude.

Turn-on Time  $(t_d + t_r)$ 

Under consideration.

Turn-off Time  $(t_s + t_f)$ 

Under consideration.

Emitter Depletion Layer Capacitance (C<sub>Te</sub>)

Collector Depletion Layer Capacitance (C<sub>Tc</sub>)

Collector Time Coefficient (TC)

Rise Time Coefficient (TR)

Fall Time Coefficient (TF)

Stored Charge (Q<sub>S</sub>)

Transient Current Ratio in Saturation (h21 E<sub>sat</sub> or h<sub>FEsat</sub>)

Collector Emitter Saturation Resistance:

- Small Signal Value (rcesat)
- Static Value (r<sub>CEsat</sub>)

SUNDRY QUANTITIES

Noise (N, n)

 At a selected input frequency, the noise figure is the ratio of the total noise power per unit bandwidth (at a corresponding output frequency) delivered to the output termination, to the portion thereof contributed at the input frequency by the input termination, whose noise temperature is standard (293+5°K) at all frequencies.

Noise Current (In)

Noise Voltage (V<sub>n</sub>)

Noise Power (P<sub>n</sub>)

Effective Noise Bandwidth (B)

**Amplification** 

- Symbol under consideration...

**Current Amplification** 

Symbol under consideration.

Voltage Amplification

Symbol under consideration.



PAGE 15

ISSUE 1

#### GAIN (G)

#### Power Gain:

- For small signals
- For large signals

Insertion Power Gain

Transducer Power Gain

Available Power Gain

Maximum Power Gain

Efficiency (η)

Collector Efficiency (nc)

#### **External Circuit Parameters**

Emitter (d.c.) Voltage Supply (V<sub>EE</sub>)

Base (d.c.) Voltage Supply (V<sub>BB</sub>)

Collector (d.c.) Voltage Supply (V<sub>CC</sub>)

External Emitter Resistance (R<sub>E</sub>)

External Base Resistance (R<sub>B</sub>)

External Collector Resistance (R<sub>C</sub>)

External Resistance connecting Base to Emitter (R<sub>BE</sub>)

Generator Resistance (R<sub>G</sub>)

Load Resistance (R<sub>L</sub>)

Load Capacitance (C<sub>L</sub>)

- The large signal power gain is the ratio of the a.c. output power to the a.c. input power under specified large signal conditions. It is usually expressed in decibels (dB).
- Symbol under consideration.
- Symbol under consideration.
- Symbol under consideration.
- Symbol under consideration.



PAGE 16

ISSUE 1

#### 3. **GRAPHIC SYMBOLS**

#### 3.1 <u>DIODES</u>

SYMBOL	DESCRIPTION
	Diode PN
	Semiconductor rectifier diode
<u>─</u> ]	Tunnel diode
— <u>H</u>	Breakdown diode, uni-directional
	Breakdown diode, bi-directional
-(1)	Bi-directional diode (transistor)

#### 3.2 <u>THYRISTORS</u>

SYMBOL.	DESCRIPTION
	Triode thyristor (general symbol)
	Reverse blocking triode thyristor, N-gate
	Reverse blocking triode thyristor, P-gate



PAGE 17

ISSUE 1

#### 3.3 <u>TRANSISTORS</u>

SYMBOL	DESCRIPTION
	PNP transistor
	NPN transistor with collector connected to the envelope
	Uni-junction transistor with P-type base
	Uni-junction transistor with N-type base

#### 3.4 <u>FIELD-EFFECT TRANSISTORS</u>

SYMBOL	DESCRIPTION
Source Drain	Junction field-effect transistor with N-type channel
	Junction field-effect transistor with P-type channel