

Thermal Laser Stimulation for MEMS characterization and failure analysis, from principles to case studies

PERDU Philippe, CNES

BEAUDOIN Felix, THALES

LAFONTAN Xavier, NOVAMEMS

BRIAND Danick, Institute of Microtechnology, University of Neuchâtel,



Purpose

- *Demonstrate how techniques primarily dedicated to Integrated Circuit Failure Analysis can be used for MEMS expertise*
- *Give a focus on Thermal Laser Stimulation techniques that are not only helpful for fault localization but also to study reliability behavior of MEMS devices*
- *Show how it brings unique information that could not be easily found by other means*
- *Validate it through two case studies*


Outline

- *Introduction*
- *Thermal Laser Stimulation*
 - Apparatus
 - Resistance change principle and application
 - Seebeck effect imaging principle and application
- *Micro-Heating Elements Suspended on Thin Membranes*
 - Micro-heating sample description
 - Reliability test results
 - TLS studies
- *Micro-relay*
 - Sample description
 - TLS studies
- *Conclusions*

Introduction

- *How can we perform MEMS expertise?*
 - **Material / mechanical approach**
 - Physical characterization to access material properties
 - Surface and volume
 - Thermal, optical, mechanical
 - Tools: Nanoindenter, profilometer, interferometer
 - Specific failure mechanism
 - Mobile parts ...
 - **Electronic point of view**
 - Electronic function: sensor, signal processing, actuator
 - Electronic FA Tools
 - **Two complementary approaches to cover “system” approach**
- *Specific approach mixing “mechanical” and “electrical” (i.e. contact)*

TLS Principle : LSM



TLS Principle : OBIRCH, TIVA

- Resistivity slightly changes with temperature. Under local thermal laser stimulation, local resistivity change occurs

$$\Delta R = \frac{\rho_0 L}{S} (\alpha_{TCR} - 2\delta_T) \Delta T$$

$$\alpha_{TCR} = 4,29 \times 10^{-3}$$

Aluminum

$$\delta_T = 2,36 \times 10^{-5}$$

- Other materials

- Metal $\alpha_{TCR} > 0$, $\delta_T > 0$

- Polysilicon or doped Si, α_{TCR} , $\delta_T > 0$

- Voltage source (OBIRCH: K. Nikawa)




$$\Delta I = -(\Delta R / R^2) V$$

- Current source (TIVA: E. Cole)

$$\Delta V = \Delta R \cdot I$$

TLS application in IC Failure Analysis


- *Direct defect localization (short circuit)*
- *Circuit BICMOS ($I = 85mA$)*
 - Leakage current on some I/O
 - $I > 100 \mu A$ instead of $I < 10 \mu A$
 - 4 interconnection layers



Si ~ 290 μm
Lightly doped



TLS principle: Seebeck Effect Imaging





- Seebeck Effect $T > T_0$
 - Two materials
 - Temperature difference
 - => induce a voltage between material
- NB_TLS
 - No Biased TLS
 - SEI Seebeck effect imaging
- $\Delta V = V_{12}$

Material	Q_{12} ($\mu\text{V}/^\circ\text{C}$)
Al / W	7,0
Al / n+ Poly	-121
Al / n+ Si (10^{20}cm^{-3})	-105

$$V_{12} = (Q_1 - Q_2)(T - T_0) = Q_{12}(T - T_0)$$

NB TLS application in IC Failure Analysis

- Vias M1-M2
- $R=7.14$ (spec $R=0.8$ Ohm)



Courtesy of Abdellatif Firiti,
ST Microelectronics



Micro-Heating Elements Suspended on Thin Membranes (MHESTM)

- *Manufacturing process*

- Si nitride (0.5 μm) deposited on Si substrate
- Pt (210 nm) and Ta (15 nm) coating
- Second Si nitride deposit (0.5 μm)
- Si etching


Applications:

- Thermal sensor
- Thermal actuator
- Gaz sensor
- ...



MHESTM reliability test


- *Performed by the Neuchâtel Institute of microtechnology*
 - Temperature measured using micro-thermocouples
 - Warping, buckling measured using an optical profilometer
 - Record of resistance value versus temperature
 - Degradation at 575°C after 2000h (resistance increases)
- « MEMS » Failure Analysis
 - Electro migration / stress migration site at the spiral start



- Identification of some critical process steps
- Why did we get this? => real time monitoring is mandatory
- Optical microscopy did not give results




NB TLS on MHESTM (1)



- *Initial (before any kind of stress)*
 - SEI Image
 - Thermocouples
 - => Bad homogeneity


» Other acquisitions

- **After stress**





- Start
- 5,8 V (138 mW)
- Stop
- Ambient temperature
- NB TLS Measure
- Start again

NB TLS on MHESTM (2)




- *Aging monitoring*
 - From 0h to 14h
 - 3 different samples
 - Same signature
- *NB-TLS applications*
 - Characterization of different process flow
 - Homogeneity issues
 - Thermal stress only
 - Mechanical stress only

MHESTM: complementary analysis (1)




MEB:
Back scattered A+B
(composition mode)





MHESTM: complementary analysis (2)

- *X microanalysis*




Micro-relay: sample description




- Mobile part (B, C, D)
- Hinge (A)
- 2 end contact in // (D)
- 2 medium contact in //
- Contact by electrostatic force (C moves down)

NB-TLS on Micro-relay



- *20x magnification*
- *Neither applied current nor applied voltage*
- *Good contact (bottom left)*
- *Poor contact (top)*
- *Open contact (bottom right)*



Micro-relay: complementary analysis (1)




- *SEM pictures of contacts*
 - Bottom left
 - Bottom right
 - Upper left (= upper right)
- *No evidence between poor and good contact*



Micro-relay: complementary analysis (2)

- *TLS analysis*
 - Check where current is flowing
 - Confirm previous NB-TLS results
- *Evidence of reliability risk*
 - Unbalanced current flow
 - Faster wear out of good contact (current flow)
 - Faster wear out of poor contact (resistance => power dissipation)
- *NB-TLS validation*
 - Reliable results (good contact)
 - No invasive (neither current nor voltage)



Conclusions

- *Thermal Laser Stimulation has been used for MEMS expertise*
 - Complement mechanical characterization by giving electric signature
 - Not Invasive, Contact less, Submicron spatial resolution
 - Well known on purely electronic behavior (such as ESD)
 - Fast access to cross parameters (mechanical + electrical), no vacuum (SEM)
 - Very helpful for reliability studies
- *Other microelectronics FA tools can be used for MEMS expertise*
 - According to mechanism Particle, fracture, fatigue, wear, stiction, ESD...
 - RX, SAM, FIB, SEM, STEM, TEM, AFM (and electrical modes)
 - Real time analysis can be performed by dynamic tools (dérivate from SDL, PICA ...)
- *Cross parameters*
- *Reliability*