

OSIP: Assessing pseudo-hermeticity on COTS with plastic encapsulated materials


ESA Contract 4000135494/21/NL/GLC/ov



UK
TÜV NORD GROUP



SP
TÜV NORD GROUP



CSIC

CONSEJO SUPERIOR DE INVESTIGACIONES CIENTÍFICAS

Luis Arriaga, Head of SAM and TMA (ALTER SP)
Gonzalo Fernandez (ALTER SP)
Derek Fraser (ALTER UK)
Szymon Bernardsky (ALTER UK)
Francisco Javier Aparicio (CSIC-ICMS)
Angel Barranco (CSIC-ICMS)

ESCCON 2023

The European Space Components Conference

7 - 9 March 2023 | Toulouse | France



Assessing pseudo-hermeticity on COTS

Outline

- **Introduction, objective and work packages**
- **Tasks description:**
 - Task 01: Investigate device plastic packaging construction (WP1000)
 - Task 02: Test techniques study (WP1000)
 - Task 03: Test technique trade-off (WP1000)
 - Task 04: Test sample selection criteria (WP2000)
 - Task 05: Test samples manufacturing (WP2000)
 - Task 06: Test plan design (WP2000)
- **Preliminary results**
- **Gathered data summary and future work**

Introduction, objective and work packages

Objective


✓ To identify.

✓ To validate.


A proper test technique that allows to assess the EEE plastic packages pseudo-hermeticity.



Robustness against moisture ingress.



Task 01: Investigate device plastic packaging construction



Task 01: Investigate device plastic packaging construction

■ Optimum materials/process parameters

Materials																																			
Mould compound	• Capling GR900C Q1L4E	<table><tr><th>Key Specifications</th><th>Unit</th><th>Capling GR900C Q1L4E</th></tr><tr><td>Filler Content</td><td>%</td><td>86.5</td></tr><tr><td>Gel Time@175°C</td><td>seconds</td><td>39</td></tr><tr><td>Tg</td><td>°C</td><td>120</td></tr><tr><td>CTE Below Tg</td><td>PPM/°C</td><td>11</td></tr><tr><td>CTE Above Tg</td><td>PPM/°C</td><td>37</td></tr><tr><td>Ionic Content NA+</td><td>PPM</td><td>3</td></tr><tr><td>Ionic Content CL-</td><td>PPM</td><td>8</td></tr><tr><td>Moisture Absorption 24 Hrs.</td><td>%</td><td>0.22</td></tr><tr><td>Flexural Strength@RT</td><td>N/mm²</td><td>150</td></tr><tr><td>Flexure Modulus@RT</td><td>N/mm²</td><td>19000</td></tr></table>	Key Specifications	Unit	Capling GR900C Q1L4E	Filler Content	%	86.5	Gel Time@175°C	seconds	39	Tg	°C	120	CTE Below Tg	PPM/°C	11	CTE Above Tg	PPM/°C	37	Ionic Content NA+	PPM	3	Ionic Content CL-	PPM	8	Moisture Absorption 24 Hrs.	%	0.22	Flexural Strength@RT	N/mm ²	150	Flexure Modulus@RT	N/mm ²	19000
Key Specifications	Unit	Capling GR900C Q1L4E																																	
Filler Content	%	86.5																																	
Gel Time@175°C	seconds	39																																	
Tg	°C	120																																	
CTE Below Tg	PPM/°C	11																																	
CTE Above Tg	PPM/°C	37																																	
Ionic Content NA+	PPM	3																																	
Ionic Content CL-	PPM	8																																	
Moisture Absorption 24 Hrs.	%	0.22																																	
Flexural Strength@RT	N/mm ²	150																																	
Flexure Modulus@RT	N/mm ²	19000																																	
Lead frame	• Base material: Cu Alloy 194 Full Hard. • Plating: ENEPIG Ni:20-80µ"Pd:0.8-6.0µ"Au:0.12-0.6µ" Selective plating with Cu Enhanced treatment.																																		
Tape	• Nitto6250L Silicon adhesive.																																		

Mould compound transfer parameters	
Clamp force	• 150 kN
Moulding temperature	• 175 °C
Mould pressure	• 9 MPa
Transfer time	• 90 s
Post cure time	• 6 h
Post cure temperature	• 175 °C

Task 02: Test techniques study


■ Introduction

✓ **Moisture ingress in plastic materials:** It is a type of absorption process whereby surface-adsorbed water molecules are dissolved or permeate into the solid plastic.

✓ **Key parameters related to moisture absorption:**

➤ **Moisture concentration:**
$$M_t = \frac{W_t - W_{dry}}{W_{dry}}$$

➤ **Moisture saturation concentration:** M_{sat}



Task 02: Test techniques study

■ Introduction


MOISTURE ABSORPTION/DESORPTION MEASUREMENTS

- Weight gain/loss
- MW resonant sensor
- Chemical analysis



FUNCTIONAL TEST

- Hygroscopic swelling
- Tg shifting
- CTE modification



OTHER CHARACTERISATION TECHNIQUES

- Porosimetry
- Wettability





Figure 1. Methods used to determine porosity and pore size distribution (PSD).



Task 02: Test techniques study


■ Introduction

Non specific techniques

Gravimetric method

Weight gain/loss is analysed

- Environmental chamber + precision balance.
- Halogen lamp moisture analyser
- Thermogravimetric analyser
- Dynamic vapor sorption analysers



$$M_t = \frac{W_t - W_{dry}}{W_{dry}}$$

MW resonant sensor

Water content is assessed through systems impedance





Fig. 1. Set-up of the microwave measurement.

Specific techniques

FT-IR spectroscopy
Karl Fisher Titration
Humidity sensors




Task 03: Test technique trade-off

- Qualitative pros and cons of the different techniques analyzed


Technique	Test method	Absorption / desorption	Readability ¹ (% wt)	In situ / real time monitoring	Sample size	Availability	Price
Environmental chamber + precision balance		Both					300-30K€
Moisture analyser							10K€
Thermogravimetric analysis							> 50K€
Dynamic Sorption Analysis		Both			12-14 mm of diameter		65 K€
Karl Fisher							15 K€
RH based moisture analysers							20 K€
MW resonant moisture sensing		Both					
FT-IR		Both					>150 k€

Task 03: Test technique trade-off

- Qualitative pros and cons of the different techniques analyzed



Task 04: Test sample selection criteria



Task 05: Test samples manufacturing

Equipment		Process Step	Sample 1 (golden)	Sample 2	Sample 3	Sample 4
LF number			PS1	PS2	PS3	PS4
Serial Number			1-120	121-240	241-360	361-480
Leadframe Plating type			Selective with AE	Selective with AE	Selective with AE	Fully Plated
Dispenser & Convection Oven	Epoxy Dispense & Oven Cure	Time/Temp: 90 mins@175°C Loctite 84-1	Time/Temp: 60 mins@150°C Loctite 84-1	Time/Temp: 90 mins@175°C Loctite 84-1	Time/Temp: 90 mins@175°C Loctite 84-1	
Fico MMSI	Mould ENCAP	Time/Temp: 90s@175°C Pressure: 9MPa Force: 150kN EMC Pellets in sealed bag thaw @RT for 2-3hours GR900C	Time/Temp: 90s@175°C Pressure: 9MPa Force: 150kN EMC Pellets in sealed bag thaw @RT for 2-3hours GR900C	Time/Temp: 90s@175°C Pressure: 9MPa Force: 150kN EMC Pellets in sealed bag thaw @RT for 2-3hours GR900C	Time/Temp: 90s@175°C Pressure: 9MPa Force: 150kN EMC Pellets in sealed bag thaw @RT for 2-3hours GR900C	
Convection Oven	Mould ENCAP Post Cure	Time/Temp: 6 Hours@175°C Force: 1Kg	Time/Temp: 6 Hours@175°C Force: 1Kg	Time/Temp: 2 Hours@150°C Force: 1Kg	Time/Temp: 6 Hours@175°C Force: 1Kg	

Task 06: Test plan design

- Objectives and test blocks

- ✓ To assess the performance of the two selected test techniques, including sensitivity, industrial process, benefits and drawbacks.
- ✓ Investigate **how** and **where** this kind of test could be allocated within the classical validation test sequences used at EEE level, considering the different test usage: as part of the device screening, evaluation test, etc.

Task 06: Test plan design

- Test plan

✓ **1st test group:** Initial status of the samples.

Samples	Manufacturing modification
Sample 1 golden type	None
Sample type 2	Less time & curing temperature (60 min & 150 °C)
Sample type 3	Less time & post-curing temperature (2 h & 150 °C)
Sample type 4	Fully plated

		Sample 1 Golden	Sample type 2			Sample type 3			Sample type 4		
Step	Test	Q0	Q1	Q2	Q3	Q1	Q2	Q3	Q1	Q2	Q3
1	1st test group	3	3	3	3	3	3	3	3	3	3
1.1	External visual inspection	3	3	3	3	3	3	3	3	3	3
1.2	Dimensions check	3	3	3	3	3	3	3	3	3	3
1.3	Weight measurements	3	3	3	3	3	3	3	3	3	3
1.4	X-ray	3	3	3	3	3	3	3	3	3	3
1.5	SAM inspection	3	3	3	3	3	3	3	3	3	3
1.6	Low pressure SEM	1	1			1			1		

Task 06: Test plan design

■ Test plan

✓ **2nd test group:** Environmental stresses → Different degradation levels → Different moisture ingress levels.

Samples	Manufacturing modification
Sample 1 golden type	None
Sample type 2	Less time & curing temperature (60 min & 150 °C)
Sample type 3	Less time & post-curing temperature (2 h & 150 °C)
Sample type 4	Fully plated

		Sample 1 Golden	Sample type 2			Sample type 3			Sample type 4		
Step	Test	Q0	Q1	Q2	Q3	Q1	Q2	Q3	Q1	Q2	Q3
2	2nd test group	3	3	3	3	3	3	3	3	3	3
2.1	No stress tests	3	3			3			3		
2.2	TC (-55 to +125 °C / 100 cycles)			3			3			3	
2.3	RH (250 h / 85°C / 85% RH)				3			3			3
2.4	TS (-55 °C to 125 °C / 25 cycles)				3			3			3
2.5	RH (250 h / 85°C / 85% RH)				3			3			3
2.6	TS (-55 °C to 125 °C / 25 cycles)				3			3			3
2.7	Baking (24 h/ 125 °C)	3	3	3	3	3	3	3	3	3	3

Task 06: Test plan design

Samples	Manufacturing modification
Sample 1 golden type	None
Sample type 2	Less time & curing temperature (60 min & 150 °C)
Sample type 3	Less time & post-curing temperature (2 h & 150 °C)
Sample type 4	Fully plated

■ Test plan

✓ **3rd test group:** Moisture sorption measurements (previously selected techniques).

		Sample 1 Golden	Sample type 2			Sample type 3			Sample type 4		
Step	Test	Q0	Q1	Q2	Q3	Q1	Q2	Q3	Q1	Q2	Q3
3	3rd test group	3	3	3	3	3	3	3	3	3	3
3.1	Dynamic sorption analysis	3	3	3	3	3	3	3	3	3	3
3.2	RH based moisture analysis	3	3	3	3	3	3	3	3	3	3

Task 06: Test plan design

Samples	Manufacturing modification
Sample 1 golden type	None
Sample type 2	Less time & curing temperature (60 min & 150 °C)
Sample type 3	Less time & post-curing temperature (2 h & 150 °C)
Sample type 4	Fully plated

■ Test plan


✓ **4th test group:** Final samples status → Correlation with the moisture sorption measurements.

Step	Test	Sample 1 Golden	Sample type 2			Sample type 3			Sample type 4		
		Q0	Q1	Q2	Q3	Q1	Q2	Q3	Q1	Q2	Q3
4	4th test group	3	3	3	3	3	3	3	3	3	3
4.1	External visual inspection	3	3	3	3	3	3	3	3	3	3
4.2	SAM inspection	3	3	3	3	3	3	3	3	3	3
4.3	Cross section	3	3	3	3	3	3	3	3	3	3
4.4	SEM inspection	3	3	3	3	3	3	3	3	3	3

Preliminary results

Samples	Sample Type	Subgroup
SN001	1 Golden type	Q0
SN367	4	Q3
SN368	4	Q3
SN369	4	Q3

■ SAM results




- SN001: Ideal manufacturing process.
- SN367, SN368 & SN369: Delaminations in the lead fingers.
- SN367 & SN368: Evolution of the delaminated area.

Preliminary results

■ Dynamic sorption analysis


- ✓ **In situ monitoring** of the weight change.
- ✓ Real time response to **different humid environments** (RH and temperature control).
- ✓ **Absorption and desorption** measurements.



Preliminary results

Samples	Sample Type	Subgroup
SN001	1 Golden type	Q0
SN361	4	Q1
SN367	4	Q3
SN368	4	Q3
SN369	4	Q3

■ Dynamic sorption analysis



- SN001: No delaminations
- SN367 & SN368: Evolution of the delaminated area.

First analysis discloses higher moisture absorption on those samples that experienced delamination evolution.

Gathered data summary and future work

- Dynamic sorption analysis allows to characterize the moisture absorption of the QFN 4x4 test vehicles.
- The modified manufacturing process and the environmental stresses seem to affect the integrity of the samples and the moisture absorption response.
- RH based moisture analysis must be performed and validated after completing the dynamic sorption analysis of the remaining samples.
- Final physical characterization of the samples must be completed.



THANK YOU!

For any question, please contact:

Luis Arriaga

Head of SAM and TMA

luis.arriaga@altertechnology.com

+34 684131400